

Alphabetical index

Alphabetical index

A

A/C

Air conditioning filter 522

Automatic air conditioning
system 298

ABS 254

ACCESSORY mode 168

Active stabilizer suspension
system 254

Adaptive front lighting system 204

AFS 204

Air conditioning system 298

Air conditioning filter 522

Automatic air conditioning
system 298

Airbags

Airbag operating conditions 127

Airbag precautions for your
child 131

Airbag warning light 577

Curtain shield airbag operating
conditions 128

Curtain shield airbag
precautions 131

Front passenger occupant
classification system 136

General airbag precautions 131

Locations of airbags 124

Modification and disposal of
airbags 135

Proper driving posture 122, 131

Side airbag operating
conditions 128

Side airbag precautions 131

SRS airbags 124

Alarm 119

Antenna 318

Anti-lock brake system 254

Armrest 442

Audio input 361

Audio system

Antenna 318

Audio input 361

AUX adapter 361

CD player/changer 321

iPod® player 341

MP3/WMA disc 331

Optimal use 358

Portable audio device 361

Radio 311

Steering wheel audio switch 363

USB memory player 354

Automatic air conditioning system

Air conditioning filter 522

Automatic air conditioning
system 298

Automatic headlight leveling

system 206

Automatic high beam system 207

Automatic light control system 202

AUX adapter 361

B	Back door	
	Back door	66
	Wireless remote control.....	59
	Back-up lights	
	Replacing light bulbs	546
	Wattage	649
	Battery	
	Checking	499
	Hybrid battery	
	(traction battery)	31
	If the vehicle has a discharged	
	12-volt battery	627
	Preparing and checking	
	before winter.....	276
	Bluetooth® audio	374
	Bluetooth® phone	386
	Brake	
	Fluid	646
	Parking brake	182
	Brake assist	254
	Break-in tips	159

C	Card key	43
	Care	
	Exterior	468
	Interior	471
	Seat belts	472
	Cargo capacity	275
	Cargo hooks	445
	CD changer	
	CD	321
	MP3	331
	WMA disc	331
	CD player	321
	Chains	276
	Child restraint system	
	Booster seats, definition	141
	Booster seats, installation	145
	Convertible seats, definition.....	141
	Convertible seats, installation.....	145
	Front passenger occupant	
	classification system	136
	Infant seats, definition	141
	Infant seats, installation	145
	Installing CRS with LATCH	
	system	146
	Installing CRS with seat belts.....	148
	Installing CRS with top tether	
	straps	152

Child safety

Airbag precautions.....	131
Back door precautions.....	66
Child restraint system.....	141
Child-protectors.....	64
How your child should wear	
the seat belt.....	95
Installing child restraints	145
Moon roof precautions	111
Power window lock switch.....	105
Power window precautions.....	107
Removed electronic key battery	
precautions	526
Seat belt comfort guide.....	92
Seat belt extender precautions	98
Seat belt precautions	96
Seat heater precautions	441
12-volt battery	
precautions	475, 504
Child-protectors	64

Cleaning

Exterior.....	468
Interior.....	471
Seat belts	472
Clock	434
Coat hooks.....	443
Compass.....	455
Condenser	495
Console box	428
Cooling system	
Hybrid system overheating.....	630
Cornering assist sensors.....	237
Cruise control	
Cruise control.....	222
Dynamic radar cruise control.....	226
Cup holders.....	426
Curtain shield airbags	124
Customizable features.....	666

D

Daytime running light system.....	205
Defogger	
Rear window	305
Side mirrors.....	102
Dimensions	638
Dinghy towing.....	294
Display	
Energy flow	36
Multi-information display	191
Trip information.....	194
Warning message.....	585
Do-it-yourself maintenance.....	481
Door courtesy lights	
Door courtesy lights.....	420
Wattage	649

Door lock	
Back door	66
Side door	63
Wireless remote control	59
Door pockets	425
Doors	
Back door	66
Door lock	48, 59, 63
Door windows	105
Power back door	66
Side door	63
Side mirrors	102
Driver's seat belt reminder light	578
Driving	
Break-in tips	159
Correct posture	122
Procedures	158
Utility vehicle precautions	266
Winter driving tips	276
Driving position memory	86

E	Electric power steering	254
	Electronic features control	191
	Electronic key	
	If the electronic key does not operate properly	624
	Electronically modulated air suspension	244
	Emergency flashers	
	Switch	566
	Emergency, in case of	
	If the back door opener is inoperative	70
	If the electronic key does not operate properly	624
	If the hybrid system will not start	620
	If the shift lever cannot be shifted from P	622
	If the vehicle has a discharged 12-volt battery	627
	If a warning buzzer sounds	576
	If a warning light turns on	576
	If a warning message is displayed	585
	If you have a flat tire	606
	If you lose your keys	623
	If you think something is wrong	573
	If your vehicle becomes stuck	635
	If your vehicle needs to be towed	567
	If your vehicle overheats	630

Engine

Accessory mode	168
Compartment	487
Hood.....	484
How to start the hybrid system ...	168
Identification number.....	639
If the hybrid system will	
not start	620
Ignition switch.....	168
Overheating.....	630
"POWER" switch	168
Engine compartment cover	488
Engine/power control unit coolant	
Capacity.....	644
Checking	493
Preparing and checking	
before winter	276

Engine oil

Capacity	642
Checking.....	489
Preparing and checking	
before winter.....	276
Engine oil maintenance data	491
EPS.....	254
EV drive mode.....	176
Event data recorder	574

F

Floor mat.....	444
Fluid	
Brake.....	646
Washer.....	497
Fog lights	
Replacing light bulbs	546
Switch.....	213
Wattage	649
Footwell light	420
Front fog lights	
Replacing light bulbs	546
Switch.....	213
Wattage	649
Front passenger occupant	
classification system.....	136
Front passenger's seat belt	
reminder light	578
Front seats	
Adjustment	77
Driving position memory	86
Flattening seatbacks	78
Front side marker light	202
Replacing light bulbs	546
Wattage	649

Front turn signal lights

- Replacing light bulbs546
- Wattage649

Fuel

- Capacity640
- Fuel gauge184
- Information650
- Refueling112
- Type650

Fuel door112

Fuel filler door112

Fuses527

G

Garage door opener449

Gauges184

Glove box424

H

Hands-free system for

- mobile phone386

Hazard lights

- Switch566

Head restraints

- Adjustment89

Head-up display197

Headlight aim544

Headlight cleaner221

Headlights

- Discharge headlight
 - precautions563
- Replacing light bulbs546
- Switch202
- Wattage649

Heaters

- Seat heaters440
- Side mirrors305

Height control

- Electronically modulated air
 - suspension244

Hill-start assist control254

Hood484

Hooks

- Cargo445
- Coat443

Horn183

HUD197

Hybrid system

- Emergency shut off system32
- Energy monitor/consumption
 - screen36
- High voltage components31
- Hybrid system indicator187
- "POWER" switch168

I

I/M test480

Identification

- Electric motor639
- Engine639
- Vehicle639

Ignition switch168

Illuminated entry system420

Immobilizer system117

Indicator lights187

Initialization

- Items to initialize675

Inside rear view mirror101

Interior lights

- Interior lights420
- Switch421
- Wattage649

J	Jack	
	Positioning a floor jack.....	485
	Vehicle-equipped jack	606
	Jack handle.....	606
K	Keyless entry	59
	Keys	
	Electronic key	43
	If the electronic key does not operate properly	624
	If you lose your keys.....	623
	Key number	43
	Keyless entry	59
	Keys	43
	Mechanical key.....	44
	"POWER" switch	168
	Wireless remote control key	59

L	Light bulbs	
	Replacing	546
	Wattage	649
	Lights	
	Door courtesy lights	420
	Emergency flasher switch.....	566
	Fog light switch	213
	Hazard light switch	566
	Headlight switch.....	202
	Interior light switch	421
	Luggage compartment light	69
	Outer foot lights.....	420
	Overhead courtesy light	420
	Personal light switch.....	421
	Replacing light bulbs	546
	Scuff lights	420
	Shift lever light.....	420
	Turn signal lever.....	181
	Vanity lights.....	433
	Wattage	649
	Load capacity	275
	Lock steering column	171
	Luggage compartment lights	
	Switch.....	69
	Wattage	649
	Luggage cover	446

M	Maintenance	
	Do-it-yourself maintenance.....	481
	General maintenance.....	476
	Maintenance data	638
	Maintenance requirements.....	474
	Meter	
	Instrument panel light control.....	185
	Meters.....	184
	Mirrors	
	Inside rear view mirror	101
	Side mirror heaters.....	305
	Side mirrors.....	102
	Vanity mirrors	433
	Moon roof	108
	MP3 disc	331
	Multi-information display	191
	Electronic features control	191
	Trip information.....	194
N	Noise from under vehicle	22

O	Odometer	185
	Oil	
	Engine oil.....	489
	Opener	
	Back door	66
	Fuel filler door	112
	Hood	484
	Outer foot lights	
	Outer foot lights	420
	Wattage.....	649
	Outside rear view mirrors	
	Adjusting and folding.....	102
	Mirror position memory.....	86
	Outside temperature display	435
	Overhead console	430
	Overhead courtesy lights	
	Overhead courtesy lights.....	420
	Wattage.....	649
	Overheating, Hybrid system	630

P

- Parking assist sensors 237
- Parking brake 182
- Parking lights
 - Replacing light bulbs 546
 - Switch 202
 - Wattage 649
- PCS 262
- Personal lights
 - Switch 421
- Power back door 66
- Power easy access system 79
- Power outlet 437
- “POWER” switch 168
- Power windows 105
- Pre-collision system 262

R

- Radar cruise control 226
- Radiator 495
- Radio 311
- Rear seat
 - Folding down 82
 - Seat adjustment 82
- Rear seat entertainment system*
- Rear turn signal lights
 - Replacing light bulbs 548
 - Wattage 649
- Rear view mirror
 - Compass 455
- Rear view monitor system 250
- Rear window defogger 305
- Rear window wiper 220
- Replacing
 - Electronic key battery 525
 - Fuses 527
 - Light bulbs 546
 - Tires 606
 - Wireless remote control battery 525
- Roof luggage carrier 271
- Reporting safety defects for
 - U.S. owners 678

S	Safety Connect	459		Seat position memory	86
	Scuff lights	420		Seat ventilators.....	440
	Seat belts		Service reminder indicators	187	
	Adjusting the seat belt	92	Shift lever		
	Automatic locking retractor.....	94	If the shift lever cannot be		
	Child restraint system		shifted from P	622	
	installation	145	Transmission.....	173	
	Cleaning and maintaining		Shift lever light	420	
	the seat belts.....	472	Shift lock system	622	
	Emergency locking retractor	94	Side airbags	124	
	How to wear your seat belt.....	91	Side marker lights		
	How your child should wear		Switch.....	202	
	the seat belt.....	95	Side mirror		
	Pregnant women,		Adjusting and folding.....	102	
	proper seat belt use.....	94	Mirror position memory.....	86	
	Reminder light.....	578	Smart access system with		
	Seat belt extender	95	push-button start		
	Seat belt pretensioners.....	93	Entry function.....	48	
	Seat heaters	440	Starting the hybrid system.....	168	
	Seat position memory	86	"SOS" button	459	
	Seat ventilators	440	Spare tire		
	Seating capacity	275	Inflation pressure.....	647	
	Seats		Storage location	606	
	Adjustment	77, 82	Spark plug	644	
	Adjustment		Specifications	638	
	precautions	81, 84	Speech command switch	391	
	Child seats/child restraint		Speedometer	184	
	system installation.....	145	Steering		
	Cleaning	471	Column lock release.....	171	
	Flattig seat backs.....	78	Steering wheel		
	Head restraint	89	Adjustment.....	99	
	Power easy access system.....	79	Audio switches.....	363	
	Properly sitting in the seat.....	122	Power easy access system	79	
	Seat heaters.....	440	Steering wheel position		
			memory.....	86	

*: Refer to "Navigation System Owner's Manual".

Storage feature.....	423
Stuck vehicle	
If your vehicle becomes stuck.....	635
Sun visors	432
Sunshades.....	109
Switch	
Display contrast adjustment	
switch	197
Display position adjustment	
switch	197
Driving mode selector switch	175
Emergency flasher switch	566
ENTER switch.....	191
Fog light switch.....	213
Hazard light switch.....	566
Head-up display main switch.....	197
Ignition switch.....	168
Light switches	202
Menu switch.....	191
Power back door opener	66
Power door lock switch.....	63
“POWER” switch	168
Power window switch.....	220
Rear window wiper and	
washer switch	220
Window lock switch	105
Wiper and washer switch	215

T

Tail lights	
Replacing light bulbs	546
Switch.....	202
Wattage	649
Talk switch	391
Telephone switch.....	391
Theft deterrent system	
Alarm.....	119
Immobilizer system	117
Theft prevention labels.....	121
Tire inflation pressure	515
Tire information	
Glossary	660
Size	656
Tire identification number	655
Uniform tire quality grading.....	657
Tires	
Chains.....	276
Checking.....	506
If you have a flat tire	606
Inflation pressure	515
Inflation pressure sensor	507
Information	653
Replacing	606
Rotating tires.....	506
Size	647
Snow tires.....	276
Spare tire.....	607
Tire pressure warning	
system.....	506, 578
Tools.....	606
Total load capacity	275
Towing	
Dinghy towing	294
Emergency towing	567
Trailer towing	280

TRAC	254
Traction control	254
Trailer towing	280, 293
Transmission	
Hybrid transmission	173
If the shift lever cannot be shifted from P	622
S mode	177
Trip information display	191
Trip meter	184
Turn signal lights	
Replacing light bulbs	546
Switch	181
Wattage	649

V

Vanity lights	
Vanity lights	433
Wattage	649
Vanity mirrors	433
VDIM	254
Vehicle dynamics integrated management	254
Vehicle identification number	639
Vehicle stability control	254
VSC	254

W

Warning buzzers	
Brake system	576
Open door	578
Seat belt reminder	578
Warning lights	
Anti-lock brake system	577
Brake assist system	577
Brake system	576
Charging system	576
Electric power steering	577

Electronic engine control system	577
Low fuel level	578
Low tire pressure	578
Malfunction indicator lamp	577
Master warning light	578
Open door	578
Pre-collision system	577
Pretensioners	577
Seat belt reminder light	578
SRS airbags	577
Tire pressure	578
Warning messages	585
Washer	
Checking	497
Preparing and checking before winter	276
Switch	215
Washing and waxing	468
Weight	
Cargo capacity	275
Load limits	275
Weight	638
Wheels	520
Window glasses	105
Window lock switch	105
Windows	
Power windows	105
Rear window defogger	305
Washer	215
Windshield wiper de-icer	306
Windshield wipers	215
Wireless remote control key	
Replacing the battery	525
Wireless remote control	59
WMA disc	331